




## Assembly Instructions

Model:5010-5013 LA High Back Chair



## User Instructions

### **A** *Seat Height Adjustment*

Flip up lever on right-side to raise or lower seat. Adjust such that your feet are adequately supported on the floor.

### **B** *Multi-Position Tilt Lock*

Recline to desired position, and flip down lever on left-side to lock. Flip up lever to release tilt-lock.

### **C** *Tilt Tension Control*

Turn side knob clockwise to provide a stronger tilt tension, and vice-versa. Adjust such that minimum effort is required to push back when reclining.

### **D** *Headrest Height*

Adjust height by holding both sides of headrest and pull up or down to your desired height.

